



Hi-Lux, Inc.

3135 Kashiwa Street, Torrance, CA 90505, Tel: (310) 257-8142, Fax: (310) 257-8096

W9294MT INSTALLTION INSTRUCTION



Front Mount



Rear Mount



Dovetail Block



You need to put the 3/8" dovetail block into the dovetail cut first. Tighten the center screw on the dovetail block and jam the block into the dovetail cut. Then you need to put the front Mount on top of the dovetail block and tighten the screws into the dovetail block from both side of the front mount as the above picture showed. The front mount is off to the left side a little bit. Install the rear mount to the position as the above picture indicated. If your rifle does not have the two screw holes, then you need to drill and tap the left receiver. Two 6-48 screws are needed for the rear mount. If you have any questions about this product, please feel free to contact us at the toll free no. 1-888-HI-LUX-12 (445-8912) or send us an e-mail to techsupport@hi-luxoptics.com.

WARNING:

You must install the mount securely before you shoot the rifle. This should be done by a competent gunsmith.